QUALITY YOU CAN TRUST.



For medical supply & medical gas installation.

SINCE 1995

INFO@IHMSGLOBAL.COM SALES@IHMSGLOBAL.COM


AVSU CATALOGUE

EXCLUSIVE DESIGN FOR IHMS.FZC



IHMS.FZC





OEM DESIGN

UP TO 4 GASES TYPE



MODULAR AVSU'S UNIT


- Multi Gas AVSUs are used to isolate a gas supply in the event of an emergency or during installation and maintenance
- Meets the requirements of HTM 02-01 & HTM 2022 Medical Gas Pipeline Systems, BS EN ISO 7396-1 Medical Gas Pipeline Systems, BS EN ISO 18082 NIST Low pressure connectors for medical gases
- Comprising ø22mm or ø28mm ball valves with copper stub pipes for brazing to the pipeline system

Flush or surface mounted installation

- Access to valve assemblies via key lock or emergency mechanism
- Emergency mechanism easily Operated with no risk of injury to Personnel
- Equipped with NIST connectors either side of the valves for connection of emergency supply or for purging, testing and gas sampling
- Available with pressure Transmitter located downstream of valves to monitor pipeline pressure, for connection to area alarm panel







UP TO 6 GASES TYPE

OEM DESIGN

VALVE MATERIAL OF CONSTRUCTION

Component	Material	
Valve body	Brass CZ122	
Ball	Stainless steel 304	
Stem	Brass CZ122	
O-rings	NBR	
Ball seals	PTFE	
Pipe Flanges	Brass CZ122	
Solders	AG 103	
Copper Stubs	In Accordance with BS EN 13348	

UAE Address:







UP TO 5 GASES WITH ALARM



UPTO 3 GASES WITH ALARM

MODULAR AVSU'S UNIT WITH ALARM

- Multi Gas AVSUs are used to isolate a gas supply in the event of an emergency or during installation and maintenance
- Meets the requirements of HTM 02-01 & HTM 2022 Medical Gas Pipeline Systems, BS EN ISO 7396-1 Medical Gas Pipeline Systems, BS EN ISO 18082 NIST Low pressure connectors for medical gases
- Comprising ø22mm or ø28mm ball valves with copper stub pipes for brazing to the pipeline system

Flush or surface mounted installation

- Access to valve assemblies via key lock or emergency mechanism
- Emergency mechanism easily Operated with no risk of injury to Personnel
- Equipped with NIST connectors either side of the valves for connection of emergency supply or for purging, testing and gas sampling
- Available with pressure Transmitter located downstream of valves to monitor pipeline pressure, for connection to area alarm panel

OEM DESIGN



UAE Address: